



8GB INTERNAL MEMORY



QUAD CORE PROCESSOR



HEADPHONE SOCKET



BUILT-IN MICROPHONE



CAPACITIVE TOUCH SCREEN (5 POINTS)



16:9 WIDESCREEN



BUILT-IN SPEAKER



G SENSOR



WIFI READY

TABLE OF CONTENTS

APPEARANCE AND BUTTONS _____	4
ACCESSORIES _____	6
TURNING ON AND OFF _____	6
BATTERY CHARGING _____	6
RUN TIME _____	6
5 POINT TOUCH-SCREEN _____	6
SLEEP MODE _____	6
LOCK / UNLOCK _____	7
HOME SCREEN ICONS _____	7
VIEW ALL APPS _____	8
APP ICONS _____	8
WIDGETS _____	9
NOTIFICATION MENU BAR _____	9
SETTINGS - WI-FI _____	10
WHY CREATE A GOOGLE ACCOUNT _____	11
GOOGLE PLAY APP _____	11
SPECIFICATIONS _____	11
FAQ _____	12
WARRANTY INFORMATION _____	13

IMPORTANT SAFETY INSTRUCTIONS AND PRECAUTIONS

- Read all instructions carefully before use.
- Retain this manual for future reference.
- Use this product only in the manner described.
- Only use a water-dampened soft-cloth to clean the surface of this product.
- The following will damage this product: water or moisture ingress, exposure to prolonged extreme heat or cold; excessive humidity, dust or sandy.
- It is recommended to thoroughly charge the device for the first time. Subsequent charges can be as needed. During charging, or extended use, the product may become warm.
- There are no user serviceable parts in this product.
- Un-authorized attempts to dismantle or repair this product will void product warranty and may result in dangerous electric shock.
- Remove data cable by pulling it from the plug, not from the cord.

MID-786

APPEARANCE AND BUTTONS:



Number	Description
1	On / OFF button (*Press and hold to turn ON and OFF)
2	Increase / Decrease Volume
3	Stereo Earphone Socket (3.5mm Jack)
4	Reset Button
5	Micro USB interface (Data Transfer, Charging, USB Storage flash drive).
6	Micro SD card slot. (Supports cards up to 32GB)
7	Built in Speaker
8	Microphone
9	Front mounted camera

MID-1086

APPEARANCE AND BUTTONS:



Number	Description
1	Microphone
2	Reset button
3	Micro SD card slot. (Supports cards up to 32GB)
4	Stereo Earphone Socket (3.5mm Jack)
5	USB interface (Data Transfer, Charging, USB Storage flash drive).
6	On / OFF button (*Press and hold to turn ON and OFF)
7	Volume Down
8	Volume Up
9	Rear mounted camera
10	Internal speakers
11	Front mount camera

ACCESSORIES

1 x 7" MID-786 / 1086, 1 x DC Power Adaptor with USB socket, 1 x Micro USB/DATA cable, 1 x User Guide

TURNING ON AND OFF

To turn ON, PRESS and HOLD the POWER button until the screen turns ON.

To turn OFF, PRESS and HOLD the POWER button until the power screen appears. Then select Power Off.

Note: At any time you can press the POWER BUTTON to enter Snooze mode or to wake from Snooze mode.

BATTERY CHARGING

You can charge your MID-786 / 1086 using the supplied DC Power Adaptor and USB/DATA cable.



You will be alerted when the battery charge falls below 15%. If the battery is completely depleted the MID-786 / 1086 will automatically turn off.

Note: If the battery has been completely exhausted, it may take a few minutes to switch the MID-786 / 1086 on once charging has begun. The MID-786 / 1086 can be used during charging however this may increase the time needed to fully charge the battery.

RUN TIME

Run time of portable devices such as this MID-786 / 1086 can be extended by reducing the screen brightness, turning off the Location function, turning off WiFi and turning off Apps that are not required. Manually turning the screen off using the power button when not in use will also prolong run time.

5 POINT TOUCH-SCREEN

The MID-786 / 1086 has 5 different touch screen behaviours.

- | | |
|-----------------|---|
| 1-TAP | Tap once to select or start a function, option or application |
| 2- TAP and HOLD | Tap and hold to select or start a function |
| 3-DRAG and DROP | Tap then drag an item and drop it to a location |
| 4-DOUBLE TAP | Double Tap an item twice to select or start a function |
| 5-SLIDE/SWIPE | Tap then slide an item up, down, left or right |

SLEEP MODE

During prolonged inactive use where no buttons have been pressed, the screen will turn off automatically to conserve power. Press the POWER button to wake the MID-786 / 1086.


Note: This can be adjusted in Display option under Settings.

LOCK / UNLOCK

When the MID-786 / 1086 is in sleep mode, press the POWER button to show the unlock screen. TAP and HOLD the LOCKED padlock icon, drag it to the UN-LOCKED padlock icon, then release.

Note: Some of the following images may be different from the actual product supplied.

HOME SCREEN ICONS



Number	Icon	Function
1		Open web browser / Voice command
2		"Swipe Down" Notification Menu Bar
3		"Swipe Down" Shortcut Menu Bar
4		View all apps
5		Increase Volume
6		Open a list of recently used applications
7		Home screen
8		Back button
9		Decrease Volume

VIEW ALL APPS



Press to view all the installed apps on your tablet




APPS ICONS

Note: Some of the following images may be different from the actual product supplied.

Icon	Function
 Chrome	Web Browser: Open Chrome web browser
 Calendar	Calendar: Create and manage daily, weekly and monthly events, set alarm clocks. <i>Note: A Google account is required</i>
 Camera	Camera: Take and view pictures and video
 Clock	Clock: Access alarm clock settings and time display
 Downloads	Downloads: Manage downloaded content
 Email	E-mail: e-mail access
 File Manager	File Manager: Access all pictures, video, music, sound clips and other files saved on the device and SD card
 Music	Music: Music player
 Settings	Settings: View settings menu
 Sound Recorder	Sound Recorder: Record sound using the microphone
 VideoPlayer	Videos: Video player

WIDGETS




Users can add or remove Widget program icons (shortcuts) from the desktop as well as move them to different desktop screens.

To add a Widget, press and hold the desired widget, drag and drop it to the desired position on the desktop. To remove an icon from the home screen, press and hold the icon until the “X” icon appears at the top LEFT of the screen. Drag the icon to the “X” and then release to delete.

NOTIFICATION MENU BAR

Swipe down over the Notification Menu Bar (top right of the screen) to display any notifications you may have. Tap the upper most section of this menu bar to display user settings. Tap again to minimize this section.

The user settings found here is WiFi Networks, Bluetooth Settings, Airplane modes, Screen Rotations, Location GPS Settings, Cast Screen Feature and Wifi Hotspots for sharing WiFi.




SETTINGS

Wi-Fi

Note: a WiFi connection is required if connecting to the internet (for email, Play Store or web browsing)

When WiFi is turned on it will automatically scan for all available WiFi networks



Tap the desired WiFi NETWORK name. If this NETWORK connects successfully, “Connected” will appear. If the NETWORK is encrypted, enter the password then tap “Connect”.

Your MID-786 / 1086 will indicate when the NETWORK connection is ready for use when the WiFi icon appears on the top right notification bar.

WHY CREATE A GOOGLE ACCOUNT

Creating a Google account allows you to talk, chat, share, schedule, store, organize, collaborate, discover, and create online. A Google account also provides user level access to Gmail, Google+ and YouTube which are all backed up online and accessible online via the cloud.

GOOGLE PLAY APP

Open the GOOGLE PLAY STORE App and set up your account. If you have an existing account select EXISTING, otherwise choose NEW to create a new account and follow the set-up steps.



SPECIFICATIONS

Operation System:	Android 6.0	
Size	7": 115 x 190 x 11mm	10": 110 x 190 x 11
CPU processor speed:	Quad Core 1.5Ghz	
Memory:	8GB	
RAM:	DDR3 1 GB	
TF card:	Up to 64GB	
Display screen:	(Capacitive multi-touch) TFT capacitive touch	
Resolution:	1024 x 600HD	
Battery and capacity:	Rechargeable Built-in type polymer battery, 2500Mah/4000Mah	
Camera Resolution:	7": 0.3MP (Front mount)	10": 0.3 / 2MP (Front Back)
Screen auto orientation:	G-sensor 3D	
Voice Recording	Built-in microphone	
Supported file types:	Video format: avi, mov, mp4, 3gp, flv Audio format: mp3, flac, aac, wav, m4a <i>(To play other formats, you will need to download the App that supports the format you intend to play)</i>	

FAQ

I can't turn my MID-786 / 1086 ON?	<ol style="list-style-type: none"> 1.Ensure your MID-786 / 1086 is charged 2. Connect the power adaptor, and then check again after sufficient charge time 3. Reset the device using the reset button
I can't hear anything through my headset, or the sound quality is very bad	<ol style="list-style-type: none"> 1.Please ensure volume is turned up and connected correctly. 2. Check the music file on another device to make sure it is not damaged. 3. Try using another pair of headphones
I can't copy files or play music	<ol style="list-style-type: none"> 1.Please check the connection to you computer 2.Ensure there is enough spare memory 3.Check the USB cable is not damaged using another device 4.Check the USB connection is inserted correctly
My MID-786 / 1086 displays a network or service error message	<ol style="list-style-type: none"> 1. Check the strength of the WiFi signal 2. Check that the WiFi service is available and operating correctly 3. When using apps like Face Book and Google play (with a lot of content) <u>for the first time</u>, a few extra minutes will be required to load all the content.
My touch screen is slow and not working correctly	<ol style="list-style-type: none"> 1. Make sure the protective film has been removed from the screen 2. Ensure that your fingers are dry and clean. 3. Restart your MID-786 / 1086 (or wait 5mins if turning on for the first time) 4. Ensure the touch screen is not scratched or damaged
My MID-786 / 1086 is frozen or a severe error has occurred	<ol style="list-style-type: none"> 1. Try closing Apps or resetting 2. Restore or reset the MID-786 / 1086 to factory default settings. 3. Reset the device using the reset button
My MID-786 / 1086 becomes hot when is use or while charging	<ol style="list-style-type: none"> 1. Some applications can consume more power than others causing the MID-786 / 1086 to become warm while in use or if used for extended amounts of time. This is normal and won't affect the life or performance of your MID-786 / 1086.
An error occurs when I open my music files	<ol style="list-style-type: none"> 1. Remove some files to make more storage space 2. Make sure the music files aren't protected by digital rights management (DRM). If the files have DRM protection, make sure that you have the license or key. 3. Make sure that file type is compatible.
The available memory on my MID-786 / 1086 is less than 8GB. Why is that so?	<p>Some of this space is required to pre-load Apps and other Software. Space is required for the OS (Operating System).</p>
My MID tablets internal memory is almost full; can I install or move the Apps to external SD card?	<p>Android 5 OS will only allow apps to be installed on internal memory. To free up the internal space: 1) Uninstall some un-used apps. 2) Move photos, music or video files to SD card.</p>
My tablet screen has cracked; will it be covered by warranty?	<p>No, physical damage is not covered by warranty.</p>

For further product information and instructions please visit our product web page at www.laserco.com.au or email support@laserco.com.au

Please note: As continuous improvements are made to this product, slight operational differences may occur. For the most up-to-date user manual, please visit our web site.

Warranty Against Defects

Laser Corporation Pty Ltd (“Laser”) warrants your new product to be free from defects in materials and workmanship for 12 months, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. The benefit of this warranty is in addition to your rights under the Australian Consumer Law and to other rights and remedies of the consumer under a law in relation to the goods or services to which the warranty relates.

Through a network of retailers and resellers, Laser will provide you with your choice of a repair, exchange (where possible) or refund (**within Dead on Arrival period**) for this product if it becomes defective within the warranty period.

This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse, normal wear and tear, neglect or improper storage.

Please retain your receipt as proof of purchase.

How to make a product warranty claim:

Step 1: Find your receipt which proves the date of purchase. Where the date of purchase cannot be verified, your place of purchase or Laser will make an assessment based on the date of manufacture, the condition of the Laser product and the type of defect.

Step 2a): Contact your place of purchase. They will assess the nature of the fault and repair, replace or refund the product as per their store refund or warranty policy.

Step 2b): If your place of purchase cannot be contacted, then you can contact Laser Customer Service with details of your defective Laser Product Phone (02) 9870 3388; or Email: service@laserco.com.au or online www.laserco.com.au/support. Our business address is: Unit 1/6-8 Byfield Street, North Ryde, NSW 2113

Step 3: Laser will issue you with a Return Authorisation (RA) number within 48 hours. When requested, send us the defective product and a copy of your receipt. Laser will cover the cost of the return delivery.

Step 4: Wait for us to contact you. Once we have received your defective Laser product for inspection, we will inform you of our assessment of your claim within 7 days. When we contact you, we will firstly let you know whether you have a valid claim under this Warranty, and if so, we will inform you whether your defective Laser product will be replaced or repaired, together with the number of days you can expect to wait to receive your replaced or repaired Laser product.

Step 5: For further details on warranty cover and returns, please check [Terms and Conditions for Warranty Returns](#) section at www.laserco.com.au/support

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

