

HDD Docking Station for 2.5"/3.5" SATA HDD User Manual

Declaration

Thank you for purchasing the LASER CASE-DOCK. Please read these instructions carefully before use.

Notice

- Make sure that all cables are connected before turning the power on.
- Do not use the Docking station in extreme hot, cold, dusty or wet environments.
- Place the Docking station on a flat stable surface away from the edge.
- Do not remove hard drives or other devices from the Docking station if it is being accessed by the computer as this may corrupt data or damage the drive or device. Please use the Safe removal tool to stop devices before removal.
- Do not drop hard drives in the bays. Place them gently on to the connectors.
- Make sure that you are protected against static discharge before handling bare hard drives

Main features

- Plug and Play. No drivers required when used on Windows 2000 or later or MAC OS9 or later
- Allows quick change over of drives
- USB 2.0 High Speed interface
- Stable base
- Back Up Software

Layout



	Description		Description
A	3.5" & 2.5" SATA / SATA II DRIVE BAY	E	HDD Ejector Lever
B	Power LED	F	USB Connection
C	HDD activity LED	G	DC POWER SOCKET
D	Backup Button (Requires software)	H	POWER SWITCH

HDD Docking Station for 2.5"/3.5" SATA HDD User Manual

Connecting the docking station

Connect the supplied USB cable to the rear of the Docking station and the other end to a spare USB 2.0 port on your computer.

Connect the AC adaptor to a power point and to the socket on the rear of the Docking station.

Do not turn the Docking station on until the hard drive has been fitted.

Connecting hard drives

Turn the Docking station off at the power switch on the rear.

Pick the Hard drive up and position the drive so the label is facing toward the right hand side of the station and the drives contacts are facing down.

Carefully lower the drive in to the correct bay and ensure that drive is fitted snugly in to the bay.

Do not jar the hard drive.

Turn the power switch on.

The computer should detect the station and the drive and assign the next available drive letter to the hard drive.


Removing the drive

To remove the hard drive from the docking station, use the "safely remove hardware" tool in the System Tray in the lower right hand side of the screen to unmount the drive.

Select the drive to stop and click on the stop button.

Turn the Docking Station OFF and allow a minute or so for the hard drive to spin down before removing it from the station.

Take hold of the drive with one hand and slowly rotate the HDD Ejector lever clockwise until the drive is free of the contacts.




Backup software installation

1. Insert the supplied CD in to the CD/DVD reader and open the folder called [PCCLONEEX_LITE_2_00_08_JM329] and then the folder named [PcCloneEx].




2. Double Click on the SETUP.EXE program to begin the installation. Click on the Install button to proceed.



3. Click on the "Next" button to accept the license agreement and continue with the installation




4. Select your preferred installation options and click on the "Install" button




5. Click on the "OK" button to finish the installation


Basic use of PCLoneEX software


1. To launch the software Double click on the desktop icon.
2. In the Quick Launch Window click on the Back up button (As circled right).




3. The message box "Please select file(s)!" will appear. Please click on the "OK" button



4. Use the left panel to select the folder or files that you want to back up. Click on the  icon to start the back up and then click the "Start" button in the confirmation box.



5. During the backup, information about the progress of the files being backed up will be displayed. You can stop the back up at any time by clicking on the "Cancel" button.




6. A pop up box will be shown when the backup is complete. Click on the OK button.

HDD Docking Station for 2.5"/3.5" SATA HDD User Manual

7. The backed up files will be now shown in the right hand panel of the window for confirmation.



8. Click on the  icon to minimise the window to the system tray.

For more detailed instructions for using this program please read the instruction manual located in the "PCClone EX Lite_ENG_.pdf" file located in the [Guide] folder of the CD

Technical specifications

Model Name	HDD Docking Station
Product Code	CASE-DOCK
Supported Drives	1 X 3.5" SATA / SATA II
Internal Interface	SATA
External Interface	USB 2.0
HDD Capacity	UP TO 1 TB
Power Supply	Input = 240 VAC 50Hz Output= 12V DC 2.0A
Casing Material	Plastic
System Requirements	
Hardware	Windows 2000/XP/Vista and Mac OS 9.0 and above
Software	Windows 2000/XP/Vista

Troubleshooting

Problem	Solution
No power to Docking Station	Check the AC adaptor is plugged in and the switch is on. Check the switch on the back of the Station.
Drive inserted in Docking Station but not shown on computer	Hard drives must be partitioned and formatted before they can be accessible by the Computer. Partition and reformat drive. Drive has been formatted with a non compatible file system. Reformat drive.
Hard Drive in Docking Station gets hot even when the drive is not being accessed.	Hard drives fitted to the Docking station are constantly spinning the platters. This where the heat is generated. Remove the drive from the Docking Station when not required.
Cannot find drivers for Windows 98/ME	Drivers for Win98/ME are not available. The use of the Docking station on operating system other those specified is not supported.

Warranty

This product is covered by a 12 month warranty that protects against manufactures defects and faults. Using this product for purposes for which it is not designed for, Heat damage, Misuse, mistreatment, impact damage or damage by liquid penetration will void the warranty.

Support

Please check the troubleshooting guide before attempting to contact support.

Please forward all support enquires to support@laserco.com.au