


LASER


SPK-BTWP



User Manual

Product Overview:

- 1 Mic
- 2 Power button: ON/OFF;
Indicator light
- 3 Play/Pause/Answer (when
call in)
- 4 Vol+/Next track: short
press for next track, long
press for Volume up
- 5 Vol-/Previous track: short
press for previous track,
long press for Volume
down
- 6 Auxiliary Input
- 7 Micro USB charging port



Instruction

Connecting the Bluetooth Device:

1. Long press the “Power” button to enter Bluetooth mode. The blue indicator light will blink quickly.
2. Turn on the Bluetooth on your mobile phone or other devices, search for “SPK-BTWP” on the list and then pair it (please input “1234” or “0000” if a password is required), the indicator light will blink slowly after pairing successfully.
3. Short press the “Play/Pause” button to play or pause music. Long press “+” for volume up or “-” for volume down. Short press “+” for next track and “-” for previous track
4. Long press “Play/Pause” button to disconnect the speaker from the current device and reset it into pairing mode.

Line-in mode:

1. Auxiliary input lets you connect portable MP3 players that don't have Bluetooth connectivity to the speaker. You could use the attached audio cable to connect the speaker with the device.
2. The speaker will change to “Line in” mode automatically and the indicator light turns red.

Hands-free Function

1. In Bluetooth mode, the music will pause and you will hear the ringtone if there is an incoming call. Short press the "Play/Pause" button to answer the call via the built-in MIC. Short press the "Play/Pause" button again to hang up the call after conversation.

2. Long press the "Play/Pause" button to decline an incoming call if you don't want to answer it.

Charging:

Connect the USB cable to an USB power adapter or an USB port of the computer, and then plug the micro USB into the micro USB port of the speaker. While charging, the indicator light is always in green. When it is full charged, the indicator light turns off.

ECO Mode:

If there is no connection within 5 minutes after power on, the speaker will automatically power off.

Troubleshooting:

Q: The speaker can be found on the Bluetooth list of your playback device but could not connect with it successfully.

A: Please long press "Play/Pause" button to reset the Bluetooth connection and try to connect it again.

True Wireless Stereo (TWS) Mode

If you have two SPK-BTWP speakers, you can pair two units together to give a definitive stereo sound experience.

1. Ensure neither speaker is paired to the device. Press and hold the " button to disconnect the speaker from the current device.
2. Turn on the Stereo Pairing mode. The blue indicator light will blink slowly.
3. Turn on the speaker 2, it will automatically search for the other speaker and connect to it.
4. The blue indicator light on the speaker 2 will blink steadily when two speakers are connected.
5. Turn on the Bluetooth of your mobile phone or other devices and search for "SPK-BTWP" on the list and then pair it (please input "1234" or "0000" if a password is required)
6. To turn off the TWS mode, press and hold the "Play/Pause" button.

Warranty Against Defects

Laser is a brand sold and marketed by Laser Corporation Pty. Ltd. ("Laser"). Laser hereby warrants your new product to be free from defects in materials and workmanship for 12 months, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. The benefit of this warranty is in addition to your rights under the Australian Consumer Law and to other rights and remedies of the consumer under a law in relation to the goods or services to which the warranty relates.

Through a network of retailers and resellers, Laser will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse, normal wear and tear, neglect or improper storage. Please retain your receipt as proof of purchase

How to make a product warranty claim:

Step 1: Find your receipt which proves the date of purchase. Where the date of purchase cannot be verified, your place of purchase or Laser will make an assessment based on the date of manufacture, the condition of the Laser Product and the type of defect.

Step 2a): Contact your place of purchase. They will assess the nature of the fault and refund or replace the product as per their store refund or warranty policy.

Step 2b): If your place of purchase cannot be contacted, then you can contact Laser. Customer Service with details of your defective Laser Product: Phone: (02) 9870 3388; or Email: support@laserco.com.au or online www.laserco.com.au/warran-ty (click on "Consumers (End Users)"). Our business address is at 1/6-8 Byfield Street, North Ryde, NSW 2113

Step 3: Laser will issue you with a Return Authorisation (RA) number within 48 hours. When requested, send us the defective Product and a copy of your receipt. Laser will cover the cost of the return delivery.

Step 4: Wait for us to contact you. Once we have received your defective Laser Product for inspection, we will inform you of our assessment of your claim within 7 days. When we contact you, we will first let you know whether you have a valid claim under this Warranty, and if so, we will inform you whether your defective Laser Product will be replaced or repaired, together with the number of days you can expect to wait to receive your replaced or repaired Laser Product. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.