

# LASER



## USER MANUAL

AO-LED18BLK & AO-LED18BLU

## PRODUCT FEATURES

- 1.Power consumption:≤0.5W
- 2.Working voltage: DC 3.7V
- 3.Charge Voltage: DC5V/500mA
- 4.Impedance:32 Ω
- 5.Frequency range:20Hz-20Khz
- 6.Sensitivity:90db
- 7.Charging time:2-3hours
- 8.Play time: FM/TF mode (4--5hours without led flashing), Bluetooth mode(3-4hours without led flashing),with led flashing ,playtime 2-3 hours.
- 9.BT version: 2.1+EDR
- 10.Audio decoding format: MP3
- 11.Microphone sensitivity: -32db
- 12.FM RANGE: 87.5-108.0MHZ
- 13.Working range: 10 -15 meters without blocking
- 14.Micro SD Max support: 16G

## INTRODUCTION

Thank you for purchasing the LASER LED BLUETOOTH HEADPHONE. Please read the manual carefully before using this device. Keep the manual for your further reference.

## OPERATION

Fully charge the headphone battery for the first time use. To charge, insert the micro USB Cable into the charging port and connect to a power source. When it is charging, the indicator light will glow red. After it had finished charging, the indicator light will go off. It takes 2-3 hours to charge.

When the headphone is running out of battery, an alarm sound will be heard. Please charge the battery immediately. If the headphones are used after this warning, the will automatically turn off after 3-5 minutes.

## POWER ON/OFF

1. Power ON: Slide the power ON/OFF switch to ON, the LED will flash blue and red.
2. Power OFF: Slide the power ON/OFF switch to OFF, then the headphones go off.

## LED FLASHING

1. The LED lights could react to the music
2. While you are listening to music ,the led lights will flash automatically. If you do

not want LED flashing of the both sides, double quick move the back-forward button ,the Led will be off. .If you need the lights be on again, re-do the action again .

### BLUETOOTH GUIDANCE

Bluetooth mode offers the features of a hands free speaker and wireless music player When you turn on the headphone, the indicator light glow blue and red, turn on the Bluetooth function on your phone, search the device name AO-LED18BLK or AO-LED18BLU and select it to connect. After successful connection, you can play music and make the phone call.

### BLUETOOTH MODE

#### 1. ANSWER/END A CALL

When a call comes in ,press the play/pause/phone button once to answer, press again to end the call.

Adjusting the volume: Press and hold the (+)or(-) button to obtain the level you want to be.

2. To make a phone call: While the headphone is in Bluetooth mode ,double short press the play /pause/phone button for 2 second to make a call which the last number you dial or answer list on your phone, if you want to end the call, press once again.

#### 3. Reject a call

Hold the play/pause/phone button for 2 seconds and then release.

### MP3 MODE

1. When turning the headphones on, insert a micro sd card into the micro sd Card Slot to play MP3. then the led lights will be flashing automatically.

2. Press back forward and skip forward button to select the song you desired.

3. Press "Press" and hold the (+)or(-) button to obtain the level you want to be.

### FM MODE

1. Press and hold the PLAY/PAUSE /PHONE KEY for 2seconds to select the FM mode, then press the play/pause button once to scan and memorize the FM radio stations.

2. Press back forward and skip forward button to select the desired channels. Press and hold the (+)or(-) button to adjust the volume.

To switch from MP3 mode to FM mode or from FM mode to Bluetooth mode, you need to press and hold play/pause/phone button for 2 second EACH TIME to choose the mode you want to play with.

## WIRED HEADPHONE

1. Plug the 3.5mm cable to "line in" port and plug the other side to the computer or other music device then could work as a wired headphone. While in line in mode, FM /Micro SD/ Bluetooth function won't work.

## Warranty Against Defects

Laser Corporation Pty Ltd ("Laser") warrants your new product to be free from defects in materials and workmanship for 12 months, from the date of purchase, provided that the product is used in accordance with 2 accompanying recommendations or instructions where provided. The benefit of this warranty is in addition to your rights under the Australian Consumer Law and to other rights and remedies of the consumer under a law in relation to the goods or services to which the warranty relates.

Through a network of retailers and resellers, Laser will provide you with your choice of a repair, exchange (where possible) or refund (within Dead on Arrival period) for this product if it becomes defective within the warranty period.

This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse, normal wear and tear, neglect or improper storage. Please retain your receipt as proof of purchase

### How to make a product warranty claim:

Step 1: Find your receipt which proves the date of purchase. Where the date of purchase cannot be verified, your place of purchase or Laser will make an assessment based on the date of manufacture, the condition of the Laser Product and the type of defect.

Step 2a): Contact your place of purchase. They will assess the nature of the fault and repair, replace or fund the product as per their store refund or warranty policy.

Step 2b): If your place of purchase cannot be contacted, then you can contact Laser. Customer Service with details of your defective Laser Product: Phone: (02) 9870 3388; or Email: [support@laserco.com.au](mailto:support@laserco.com.au) or online [www.laserco.com.au/warranty](http://www.laserco.com.au/warranty) (click on "Consumers (End Users)"). Our business address is at 1/6-8 Byfield Street, North Ryde, NSW 2113

Step 3: Laser will issue you with a Return Authorisation (RA) number within 48 hours. When requested, send us the defective Product and a copy of your receipt. Laser will cover the cost of the return delivery.

Step 4: Wait for us to contact you. Once we have received your defective Laser Product for inspection, we will inform you of our assessment of your claim within 7 days. When we contact you, we will firstly let you know whether you have a valid claim under this Warranty, and if so, we will inform you whether your defective Laser Product will be replaced or repaired, together with the number of days you can expect to wait to receive your replaced or repaired Laser Product.

Step 5: For further details on warranty cover and returns, please check **Terms and Conditions for Warranty Returns** section on [www.laserco.com.au/warranty](http://www.laserco.com.au/warranty)

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.