


# NAV-PEDO10

# QUICK START GUIDE



## WHAT DO THE BUTTONS DO

Digital Display



## What's in the box

1 x NAV-PEDO10, 1 User Quick Start Guide

## Correct mounting

Mount the pedometer as close to the center of your body as possible.

## Navigating the menus

- Repeatedly press the MODE button to move through the read-out options: MILES, KM, CALS and [BLANK] (Step Counter)
- Note: You can press the SET button to return to the Step Counter screen from any MENU feature.

## Setting your stride and weight

- From the Step Screen, press the SET button to enter your Stride and Weight information
- The first screen shows the letter "L" and with 2 numbers flashing. This is the stride measurement in CM's
- While the numbers are still flashing press the MODE button to adjust the figure in increments of 5 CM's
- Press the SET button to move to the weight screen. The letter shown looks like a reversed number 7.
- Again use the MODE button to adjust the increments to intervals of 5 Kg's, while the digits are flashing.
- Wait 3 seconds without pressing any buttons to save the data and return back to the STEP counter screen.

## Step Counter Function

- Select the Step counter screen.
- The counter will start working when movement is detected.
- To reset the counter, press the UP button until the counter returns to 0 (Zero)

## Distance Travelled

- Press the MODE button until "KM" is displayed (or "MILE" for imperial measurements)
- The counter will then start working when movement is detected.
- To reset the counter, press the UP button until the counter returns to 0 (Zero)

**LASER**

## Calorie Calculations

- Press the MODE button until the "CALC" is displayed
- The counter will then start working when movement is detected.
- To reset the counter, press the UP button until the counter returns to 0 (Zero)

## Product Specification

Counts up to 99,999 steps  
Measures distance travelled up to 99,999 Km's or 99,999 Miles  
Calculates up to 9999.9 calories burnt

Metric stride range: From 30 to 180 CM's. 5 CM Intervals  
Weight range: From 10 to 150 Kg. 5Kg intervals.  
Auto Power off: The unit will turn off after 1 minute of no activity. The current data will be saved.  
Battery: 1 x 1.5V LR44 (AG-13) Coin cell

## FAQ

Questions	Answer
All my steps are not being counted?	Please ensure the unit has been mounted correctly and that the steps you are taking are uniform (eg. Half steps or shuffling may not produce enough downwards force to trigger the counter)
I can-not see the screen very well?	Try replacing the battery if the screen is very dim. Otherwise, in certain cases, the temperature may be too low to the internal circuitry to work correctly. .
The LCD screen has turned black and I can't see anything?	This usually occurs when the unit has been exposed to direct sun light for a period of time. Try moving the screen out of direct sun and the screen will return to normal operation.

Auto Power off: The unit will turn off after 1 minute of no activity. The current data will be saved.

For further product information and instruction please visit our product web page at [www.laserco.net](http://www.laserco.net) or email [support@laserco.com.au](mailto:support@laserco.com.au)

Please note: As continual improvements are made to this product, slight operational differences may occur.  
For the most up-to-date user manual, please visit our web site.

The logo for LASER, featuring the word "LASER" in a stylized, blue, italicized font with a white outline. The letters are bold and modern. Below the logo is a thick blue horizontal bar that tapers to the right.

## Warranty Against Defects

Laser Corporation Pty Ltd ("Laser") warrants your new product to be free from defects in materials and workmanship for 12 months, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. The benefit of this warranty is in addition to your rights under the Australian Consumer Law and to other rights and remedies of the consumer under a law in relation to the goods or services to which the warranty relates.

Through a network of retailers and resellers, Laser will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse, normal wear and tear, neglect or improper storage.

Please retain your receipt as proof of purchase

### How to make a product warranty claim:

Step 1: Find your receipt which proves the date of purchase. Where the date of purchase cannot be verified, your place of purchase or Laser will make an assessment based on the date of manufacture, the condition of the Laser Product and the type of defect.

Step 2a): Contact your place of purchase. They will assess the nature of the fault and refund or replace the product as per their store refund or warranty policy.

Step 2b): If your place of purchase cannot be contacted, then you can contact Laser . Customer Service with details of your defective Laser Product: Phone: (02) 9870 3355; or Email: [service@laserco.com.au](mailto:service@laserco.com.au) or online [www.laserco.net/support/warranty](http://www.laserco.net/support/warranty) (click on "Consumers (End Users)"). Our business address is at 1/6-8 Byfield Street, North Ryde, NSW 2113

Step 3: Laser . will issue you with a Return Authorisation (RA) number within 48 hours. When requested, send us the defective Product and a copy of your receipt. Laser will cover the cost of the return delivery.

Step 4: Wait for us to contact you. Once we have received your defective Laser Product for inspection, we will inform you of our assessment of your claim within 7 days. When we contact you, we will firstly let you know whether you have a valid claim under this Warranty, and if so, we will inform you whether your defective Laser Product will be replaced or repaired, together with the number of days you can expect to wait to receive your replaced or repaired Laser Product.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.



NAVIG[8]R

**PRECISION**  
gaming accessories

**CONNECT**

**naum8**  
GPS ESSENTIALS



The LASER logo, with the word "LASER" in a bold, blue, italicized font, positioned above a blue horizontal bar that tapers to the right.